



## DDTS E1.04B DTS HERITAGE FLOOR LINE DEFLECTION SLIP JOINT

DECOPLAST DTS HERITAGE - 6/1/2016

### NOTES:

1. See DDTS G1.01 A, B or C for Drainage Options.
2. See DTS G1.02 for Drainage Termination Options.
3. Sliding stud connection. Slotted track typical.
4. Sheathing screws for upper floor sheathing are to be fastened into track at under side of slab. Do not fasten screws for upper sheathing into studs of lower story.
5. CAUTION: If nested double tracks are used for deflection, sheathing screws must not interfere with track sliding

Disclaimer: The design, specifications, and construction shall comply with all local building codes and standards. Decoplast installation guidelines are for general information and guidance only and Decoplast specifically disclaims any liability for the use of this design, and for design, engineering, or workmanship of any project. The assembly shall be designed to prevent condensation within the assembly. The designer and the user shall provide final drawings and specifications. Products shown other than those manufactured by Decoplast are shown for clarity of the Decoplast product only. Contact the manufacturer of such other products for installation instructions.