



STEP 1: WeatherTrek® (OR EQUAL) UNDER SILL

CUT WeatherTrek® APPROXIMATE SIZE SHOWN. STAPLE INTO PLACE AT BOTTOM OF THE ROUGH OPENING. IMPORTANT! WeatherTrek® SHOULD ONLY BE STAPLED ALONG THE TOP EDGE.



STEP 2 : INSTALL FLASHING MEMBRANE "BANDAGES"


PEEL PROTECTIVE BACKER FROM DECO-SHIELD AND INSTALL DIAGONALLY AT SILL CORNERS AS SHOWN. SHEATHING OR WeatherTrek® SHOULD NOT BE VISIBLE AT THE CORNERS OF THE ROUGH OPENING.



STEP 3: CUTTING DECO-SHIELD FLASHING MEMBRANE


CUT A PIECE OF DECO-SHIELD 8" (200 MM) LONGER THAN THE ROUGH OPENING WIDTH. MAKE 2 SMALL CUTS THROUGH THE MEMBRANE AS SHOWN.

NOTE: SELECT DECO-SHIELD WIDTH 6" (150 MM) OR 12" (300 MM) AT LEAST 2" (50 MM) WIDER THAN THICKNESS OF SUBSTRATE WALL.



STEP 4: FOLDING DECO-SHIELD FLASHING MEMBRANE

FOLD MEMBRANE TO CONFORM WITH ROUGH OPENING. PEEL PROTECTIVE BACKER FROM MEMBRANE TO EXPOSE ADHESIVE



STEP 5: INSTALLING THE DECO-SHIELD FLASHING MEMBRANE

INSTALL THE "SELF STICKING" DECO-SHIELD AT THE ROUGH OPENING. MEMBRANE SHOULD LAP OVER THE PREVIOUSLY INSTALLED BANDAGES AND WeatherTrek®.

DDTS G1.03A DTS HERITAGE ROUGH OPENING PROTECTION

DECOPLAST DTS HERITAGE - 6/1/2016

Disclaimer: The design, specifications, and construction shall comply with all local building codes and standards. Decoplast installation guidelines are for general information and guidance only and Decoplast specifically disclaims any liability for the use of this design, and for design, engineering, or workmanship of any project. The assembly shall be designed to prevent condensation within the assembly. The designer and the user shall provide final drawings and specifications. Products shown other than those manufactured by Decoplast are shown for clarity of the Decoplast product only. Contact the manufacturer of such other products for installation instructions.